

Not all of my phone's cameras appear in the camera menu. Why is that?

Most manufacturers deliberately restrict access to sensors for third-party applications, with exceptions for the main and front cameras. However, the mcpro24fps app often detects more cameras than the manufacturer allows. If there are still invisible modules in your phone, it's highly unlikely that they can be activated and used by a third-party application.

This issue is particularly prevalent in OnePlus devices, stemming from intentional limitations placed on the functionality of secondary camera modules. We recommend addressing the unfairness of such discrimination [on the manufacturer's forum](#).

Just a reminder that with the [free mcpro24fps Demo](#) app, you can independently test all the features you're interested in on your phone, explore the interface, and discover the unique tools of professional video camera.

🕒Revision #1

★Created 20 March 2024 13:14:38 by Admin

✎Updated 20 March 2024 13:16:04 by Admin